



Quality Wood Finishing Products®

#8000

Hi-Def Glaze

High Viscosity for a Variety of Designer Faux Finishes. PreCat System Only.

Woodwright's Hi-Def Glaze contains No HAPS and Ultra Low VOC. With a thicker formulation, this product allows for a variety of faux finishes and design effects. Enjoy the low odor of Hi-Def Glaze! Hi-Def Glaze is available in any solid color, even metallics. You can feel confident applying this glaze under any Woodwright Precatalyzed Varnish. Easy wiping with good open time to work the glaze on large pieces. Come to The Woodwright School to learn these techniques. Call for a class schedule.

DIRECTIONS FOR USE

Use with Solid Color Varnish (Paint):

1. Apply PreCat primer or 1st PreCat color coat. Allow to dry completely. Sand as usual.
2. Apply solid color PreCat varnish or 2nd PreCat color coat. Allow to dry completely. Do not sand until you are ready to glaze.
3. When you are ready to glaze, sand surface with 320 or 400 grit sandpaper.
4. Apply glaze as desired. (When applying over whites or pastels glaze will change the overall color of your piece. To reduce this effect wipe over the surface with a cloth dampened with mineral spirits after applying glaze.)
5. Allow to dry for 1 hour and not more than 2 hours.
6. Apply clear PreCat sealer. Let dry. Sand.
7. Apply PreCat topcoat.

Use with Stain:

1. Apply stain, as usual. Allow to dry.
2. Apply clear PreCat sealer. Allow to dry. Do not sand until you are ready to glaze.
3. When you are ready to glaze, sand with 320 or 400 grit sandpaper.
4. Apply glaze as desired. Allow to dry for 1 hour and not more than 2 hours.
5. Apply 2nd coat of clear PreCat sealer. Allow to dry. Sand, as usual.
6. Apply PreCat topcoat.

